BEFORE REQUESTING SERVICE

Showcase sometimes stop running when thermostat turns off

REQUIRED INFORMATION

- Nature of malfunction
 (as accurately as possible)
- 3 Serial number 2 Product number
 - (inscribed on badge)
- **(** Customer's name, address, phone number
- (5) Year and date of purchase
- Desired date for service visit

NOTICE:

To replace the power card and light, place look for maintenacne, personal

INSTRUCTION MANUAL

	• BEFORE REQUESTING SERVICE · · · · · · · · · · · · · · · · · · ·	● IN CASE OF THE FOLLOWING · · · · · · · · · · · · · 6	• CLEANING · · · · · · · · · · · · · · · · · · ·	 ● HOW TO USE · · · · · · · · · · · · · · · · · · ·	$ullet$ SAFETY PRECAUTIONS $\cdots \cdots 1 \sim 3$	CONTENTS
1						

before operating the units. Please read these instructions completely

SAFETY PRECAUTIONS

- To ensure proper use, please thoroughly study these SAFETY PRECAUTIONS before operating the
- to minimize risks that could cause serious damage and injury to you or other persons. The safety precautions are divided into WARNINGS and CAUTIONS. Cases where improper handling of the unit could lead to death or serious injury are listed under the 25WARNING* heading. However, the cases listed under the 25CAUTION* heading could also lead to serious results. To ensure the safety, The purpose of the safety precautions in this manual is to ensure safe and correct use of the unit adhere strictly to both types of safety precautions.

WARNING

Improper handling of the unit could lead to death or serious injury.

CAUTION

improper handling of the unit could lead to serious results depending on the circumstances.

- Text set off by the exclamation mark contains information that should be strictly adhered to.
 After reading the instruction manual, store it an easily accessible place where the user(s) of this product can easily find it.
- ◆ PRECAUTIONS FOR INSTALLATION

WARNING



installation should be performed only by the dealer or a qualified expert. Attempting to install the unit yourself could result in water leakage, refrigerant leakage, electrical shock

PRECAUTIONS FOR USE

WARNING



All repairs, disassembly and modifications should be performed only by qualified lechnicians. Attempting to perform these yourself could result in a fire, malfunction, and injury.




Never splash water directly onto the product or wash with water as short-circuit and electrical leakage could result.

personat injury

11

falling shelves and products could cause performed, the unit could tip over and enough or installation is incorrectly






Never put flammable or volatile substances into the unit as explosion and fire could result

ď 573

) <

B







Never use flammable spray cans or leave flammable substances near the unit. result in explosion and fire Sparks from electrical switches could





SAFETY PRECAUTIONS

™WARNING



20

The cooler is intended for storage and display of beer and beverages for sale. Do not use for other purpose than the intended as this could adversely affect items placed in the unit.







fan is rotating at high speed inside the outlet. Injury, electrical shock and improper operation could result.

Into the cold air suction outlet. A circulation Never attempt to insert fingers, sticks, etc.



electrical leakage and electrical shock.



If you find gas leakage, please don't touch the chest ireezer, and close gas and open the door for ventilation. Gas leakage cause explosion, fire, and fire injury.

install the unit in a location where the floor is sturdy enough to support the load of the unit. If the floor is not sturdy








Store the unit in a location where it is not exposed to rain. Using a unit that has been exposed to rain could result in

electrical teakage and electrical shock

(3)







Leave disassembly and disposal of the unit to qualified experts.






the compartment. precautions so that the door cannot be completely closed. This will minimize risk that a child becomes trapped inside Should the unit need temporary storage, make sure not to store the unit in a location where children play and take

N


SAFETY PRECAUTIONS

WELL VENTILATED PLACE **△** WARNING

Please make more than 10cm space between Chest freezer and wall. If there are no space, cooling capac..y can drop down.



leakage circuit breaker is installed, electrical shock could result. If installation in a damp location is unavoidable, also install an electrical







Disconnect the power cord plug from the wall outlet before moving the unit and make sure that the power cord is not damaged during transport. A damaged power cord could result in electrical shock and/or fire





Do not push hand against or apply excessive lorce to glass surfaces as the glass could break and cause injury.

Grasp the handle when closing the door. Holding at other positions could result in pinched fingers and injury.








Make sure that the unit does not tip over or fall when it is moved. A falling unit could cause serious injury.

When disconnecting the power cord plug from the wall outlet, hold at the plug main body close to the outlet. Pulling the cord could cause wire breakage, possible resulting in overheating and fire.





3



shelf could fall downand cause injury. correctly. An improperly attached Be sure attach and secure shelves



w

HOW TO USE

BEFORE USE

- Remove shipping package tape, etc, and leave doors open ventilation for a while
- The unit is cleaned before shipment. However, clean the compartment interior once after delivery.
- Please insert power supply plug into the wall outlet , single-phale to cat voltage
- Allow the unit to operate for about 1 hour to cool the compartment before placing items in the cooler

WAIT 5 MINUTES OR MORE BEFORE RE-STARTING

circuit-breaker, the compressor may be overloaded, and/or other damage may occur Restarting the unit immediately after it has been turned off may cause fuses to blow and activate the

TEMPERATURE ADJUSTMENT

Thermostat was adjusted using temperature at factory. To adjust it, turn right could cause temperature in nsumption unnecessarily. showcase down. To raise the temperature, turn it left. Excessive refrigeration will increase electricity co-

DRAIN TRAY

- Defrosting is performed automatically and drain water is collected in the drain tray.
- Water is in the drain tray is evaporated automatically. In humidity, large amount of water in the drain tray, so please throw away drain water once a day.

EFFICIENT USE

Flease follow the below instruction, you could save energy.

- To prevent cold air from escaping, open and close the door quickly and keep the door opened for as short a time as possible
- Please install the unit in the place which is well-ventilated

SHELF HEIGHT ADJUSTMENT

The shelf height can be adjusted

Arrange the shelves in accordance with the dimensions of the items to be placed in the cooler.

۵

HOW TO USE

PLACING ITEMS IN THE SHOWCASE

the items will not be adequately retrigerated. Pay attention to the following points This showcase employs a forced circulation of cold air system. If circulation of cold air is obstructed

- Do not let items obstruct the cold air inlet and suction outlet
- Place items so that they do not protrude from the shelves. The gap between the shelves and the
- door is used for circulation of cold air Place items evenly on all shelves
- Please do not display goods on the bottom. Please put goods on the shell

CLEANING



To prevent any electrical shock hazards or injury by rotating circulation fan, always disconnect the power cord plug from the wall outlet before cleaning.

EXTERIOR AND COOLER COMPARTMENT

Wipe with a soft, dry cloth. If very soiled, wipe with a cloth that has been moistened with a detergent Then wipe with a cloth that has been dipped in water.



WARNING: Do not splash water directly onto the cooler and do not wash with water. Short circuit and electrical shock could result.

- Clean the cooler regularly to keep it clean at all times
 Never use polishing powder, soap powder, benzine, oil or hot water as these will damage the painting and plastic components.



2 CHECKS

- To ensure the safety, perform the following checks after cleaning.

 It is the power cord plug firmly inserted into a dedicated wall outlet? Confirm that the plug is not
- abnormally hat.

 Check the power cord for cracks and damage. Should the slightest irregularity be observed. confact the dealer from whom you purchased this unit or our customer's service.

IN CASE OF THE FOLLOWING

POWER FAILURE

Keep opening and closing of the door to a minimum.

Avoid placing new items in the cooler as this will raise the temperature inside the compartment

2 WHEN NOT USED FOR A LONG PERIOD

Remove all items from the compartment and disconnect the power cord plug from the wall outlet

Clean the compartment interior and wipe away all water.

To prevent mold formation and bad smell, leave the door open to dry the compartment completely.

3 TRANSPORTATION

Disconnect the power cord plug from the wall outlet.

When moving the cooler, make sure that the feet do not damage the power cord. Do not let the feet hit against floor steps, thresholds, etc.

4 TEMPORARY STORAGE

door from the inside. Make sure not to store the unused cooler at a location where children play. Should a child enter the compartment and the door is closed, the child may not be able to open the Affix a piece of wood letc. Between the door and main unit to prevent complete closing of the door

BEFORE REQUESTING SERVICE

Please check the following items if you encounter problems with the unit. If the problem continues after taking the proper remedial actions, disconnect the power cord plug from the walt outlet. you purchased this unit and be ready to provide information as listed in "REQUIRED INFORMATION" Transfer the items stored in the cooler to a box or other container. Then contact the dealer from whom



To prevent any electrical shock hazards, do not disconnect the power cord plug from the wall outlet with wet hands.

0

Ċ7